



- Power Button must have the green light on to work, if you need to turn it off just press again until green light goes off.
- To change from heating to aircon (or vice versa) press the function button to get to preferred function.
- At this point you can change the temp by using the circular button at the top or bottom to increase or decrease the temperature. Please note if heating the room we recommend the minimum temperature to be 25' to start with in order for the system to heat the room sufficiently. Also, it will take about 20-30mins to kick in before heat comes out so, please allow this time to pass. You can decrease the temp again if you wish.
- Once the room is at the preferred temperature the system will stop but restart once temperatures drops or changes.
- To change the fan speed, press the "Fan Speed" Button on the panel and use the circular button at the top or bottom to increase or decrease the speed.
- The button in the centre is a return button that will take you back to the main screen, please press this button once amendments have been made.